# NOPM-XP

The NOPM-XP includes 10 power and 10 sense spare contacts for 5 NO2MW-XP Chassis assemblies.


All rights reserved / 12.10.2024