



ASSEMBLY INSTRUCTION

XLR Chassis TOP

NC3FDX-TOP & NC5FDX-TOP with SCFDX-TOP
NC3MDX-TOP & NC5MDX-TOP with SCMDX-TOP




✓ IP65 RATED AND TOP-APPROVED.

1 Connector installation

Any TOP XLR chassis connector

4x Screws



ATTENTION:
Tightening torque
 $M_A = 40 \text{ Ncm}$

Equipment / Panel




Lubricate O-Gasket with silicon on all 4 screw holes.

2 Mount the sealing cover



A Insert the ribbon through the dedicated slot.




B (1) Split the ribbon and (2) put through the cover.




C Tighten the ribbon

3 Panel Cutout (Rear Side)



4 Recommended screw



M3 stainless steel countersunk type

Find more details of XLR Chassis on www.neutrik.com.



Draft. Nr.: BDA 553 V4
Update: 2023-03-21

Neutrik AG | LI-9494 Schaan
www.neutrik.com

Data subject to change without prior notice. © 2023 NEUTRIK®. NEUTRIK® are registered trademark of Neutrik AG. ALL RIGHTS RESERVED.

NEUTRIK
A brand of the Neutrik Group