




ASSEMBLY & SAFETY INSTRUCTION

etherCON® Magnetics | A & B-Series



NOTE:

- Attention: this Product is strictly not intended for use in PoE systems.
- This product is designed to be installed built-in electronic devices.
- This is product is strictly not intended to be used within explosive environments.



Assembly

- Install the receptacle in the panel cutout.
- Finish the installation and fasten the screws.
 - ▶ Use the special Neutrik A-screw to fixing.
 - ▶ **max. Torque 40 Ncm.**

Find more details of
connectors on
www.neutrik.com.



Neutrik AG LI T: +423 / 237 24 24 F: +423/232 53 93
Neutrik Americas Inc. USA T: +1 704 / 972 3050 F: +1 704/438 9202
Neutrik (UK) Ltd. UK T: +44 1983 / 811 441 F: +44 1983/811 439
Neutrik Vertriebs GmbH DE/NL/AT/DK T: +49 8131 / 280 890 F: +49 8131/280 830

Neutrik France FR T: +33 1/4131 6750 F: +33 1/4131 0511
Neutrik Tokyo Ltd. JP T: +81 3/3663 4733 F: +81 3/3663 4796
Neutrik Hong Kong Ltd. HK T: +852/2687 6055 F: +852/2687 6052

Draft. Nr.: BDA 633 | Update: 2021-09-07 | Data subject to change without prior notice. © 2021 NEUTRIK®, NEUTRIK® are registered trademark of Neutrik AG. ALL RIGHTS RESERVED.

www.neutrik.com

NEUTRIK®